

SINGER® MODEL 2662

The Pleasures of Sewing!

Discovering completely new sides to your talents is easy and great fun with the SINGER® 2662. It lets you realise new ideas quickly and conveniently every time they spring to mind.

No matter where your interests lie – trendy fashion, unique home decors or just everyday sewing:

With 39 stitch programs, including decorative stitches for beautiful embellishments, you are well-prepared for all occasions. From stretch stitches to handy overlock programs to the no-hassle one-step buttonhole – you'll enjoy the tremendous versatility of the

SINGER® 2662 every time you start sewing!


So much comfort – and so easy to use!

The SINGER® 2662 is an all-rounder that simply makes sewing more fun:

- > **The adjustable presser foot pressure:** Ensures easy handling of delicate materials.
- > **Extra-high presser foot lift:** Provides enough space for heavy materials, or multiple fabric layers.
- > **Fast and easy changing of presser feet thanks to snap-on/off convenience!**
- > **Easy, one dial stitch selection**
- > **Drop feed control:** For quilting and embroidery, or for darning.
- > **Extensive range of accessories**
- > **Easy flat bed/free arm conversion**

All stitch programs at a glance:

A vast range of essential stitch programs to choose from: A perfect one-step buttonhole, professional utility stitches, elastic overlock and flexi stitches, plus decorative patterns for beautiful embroideries!



> Time-saving solutions make sewing an easy task:

Needle threading is a snap!

No need to look for the needle's eye! Simply place the thread into the automatic needle threader and pull it through – within seconds the needle is ready to start.



Empty bobbin?

The "no jam" drop-in bobbin system makes bobbin changing and cleaning exceptionally simple. Thanks to fast and easy bobbin insertion from the top!




Easy switch to stretch stitches!

This clever switch lets you switch between non-elastic and stretch stitch programs in seconds.



Stitches for all occasions!

Seaming? Stretch stitches for today's elastic materials? Or simply a beautiful decorative finish? Just choose from the great variety of stitch programs built into the SINGER® 2662.



Perfect buttonholes – sewn in a flash!

Simply place the button in the buttonhole foot's guide. The SINGER® 2662 measures the button and sews a matching buttonhole in one simple step.



SINGER®

AT HOME WORLDWIDE

Unit 2/106 Grose Street Parramatta NSW 2150
Phone (02) 9630 7188 Fax (02) 9630 8199
www.singerco.com.au Email: info@singerco.com.au

© 2004 Singer Corporation Stutensee / All Rights Reserved

SINGER® MODEL 2662



With automatic one-step buttonhole

SINGER®

> SINGER® MODEL 2662

The Incredible Multi Talent!

- > An all-round sewing machine: For modern, high-performance sewing!
- > 39 Stitch programs
- > Automatic needle threader
- > Top drop-in bobbin